


Druckluft-Nadelentrost Air Needle Scaler



Nr No	Bezeichnung	Description	Stk Qty
1	Gehäuse	Housing	1
2	Hintere Endplatte	Rear End Plate	1
3	Ventilplatte	Valve Plate	1
4	Stellstift B	Set Pin B	1
5	Stellstift A	Set Pin A	1
6	Vordere Endplatte	Front End Plate	1
7	Kolben	Piston	1
8	Zylinder (Hex)	Cylinder (Hex)	1
8	Zylinder (Rund)	Cylinder (Round)	1
9	Feder	Spring	1
10	O-Ring	O-Ring	1
11	Schaltventil	Switch Valve	1
13	Buchse	Bushing	1
14	O-Ring	O-Ring	1
15	Auslöser	Trigger	1
16	Stift	Pin	1
17	O-Ring	O-Ring	1
18	Klemmmutter	Clamp Nut	1
19	Hammer	Hammer	1
20	Nadel	Needle	19
21	Nadelhalter	Needle Support	1
22	Feder	Spring	1
23	Schraube	Screw	3
24	Hülse	Sleeve	1